Advanced Programming Lesson: Menu System

EV3LESSONS.COM AND DROIDS ROBOTICS



What is a Menu System and Why Use It?

- A menu system (also called a Sequencer or Master Program) is an organized way to easily run programs without having to search for the code
- > Allows you to skip missions
- This more advanced lesson allows you to repeat failed missions



Step 1: Convert Missions to My Blocks



You need to convert each mission into its own My Block

If you don't know how to make a My Block, see the Intermediate lesson on My Blocks


There is no Step 1 and 2 in the EV3 Code file. Learn Step 1 and 2 from the Powerpoint/PDF and then continue with Step 3 in the EV3 Code file.

Step 2: Add a Current Mission Variable

Variables can be used to store information such as a sensor reading. In this program, we are going to use a variable to store the current mission that we are running.

To create a variable:

- 1. Add a variable block
- 2. Select the type of variable by changing the mode to "Write X" where X is one of Text, Numeric, Logic, Numeric Array or Logic Array. Since we are storing the mission number chose Numeric.
- 3. Click on the box at the top right and select Add Variable. For this program, create a variable called "Mission Number"



Read

Variable Types

Different types of variables can store different types of information.


- 1. Text any text, e.g.: "FLL is great" or "Run 2"
- 2. Numeric any number, e.g.: 5, 5.2 or -4.22
- 3. Logic True or False
- 4. Numeric Array a collection of numbers, e.g.: (5,2,2) or (3,4,5,6)
- Logic Array a collection of true/false values, e.g.: (T, T, F) or (F, F, T, F)

In this lesson, we only use numeric variables. Logic variables and arrays will be covered in another lesson.

Step 3: Display Current Mission Choice


You can combine a switch block set to numeric mode and a variable block set to read to display the current mission name

You should select just the switch block and create a My Block called Display_Mission.



Step 4: Increasing/ Decreasing Mission Choice


You can use a wait for menu button block and a switch to decrease the mission number if you hit the up button. The down button choice (Tab 5) is similar but increases the mission number.



Step 5: Using a Variable to Run Chosen Mission


You can combine a switch block set to numeric mode and a variable block set to read to run a specific mission

You should select just the switch block and create a My Block called Run_Mission.



Code: Menu Sequencer

You can combine the previous steps to create a menu-based sequencer that lets you select the mission using the up and down arrows



Credits

- This lesson was written by Sanjay and Arvind Seshan from Droids Robotics.
- •Feel free to use and modify, but credit the original authors.
- •More lessons are available at www.ev3lessons.com

